IN8063 Window Grilles / Blanks - Generic



KIT CONTENTS		EXAMPLE IMAGE
FX4090 X20 (No8x1/2" SELF-TAP SCREW)	It is important that care is taken when drilli and fixing to your vehicle.	ing
	You should note that it is the responsibility of the installer/s to ensure that we drilling holes in to your vehicle to take fixings, care must be taken to ensure there is no possibility of causing damage to the vehicle. Whilst every effort has made to ensure our products can be safely fitted, changes to vehicles somet occurs so it's always necessary to check before drilling. Always wear safety gluwhen drilling.	e that is been times
	If in doubt refer to the vehicle manufacturer dealership.	"s
OOLS REQUIRED	INSTRUCTIONS	
H SCREW DRIVER X 1	1. Window grilles / blanks can be handed and are often different size suit the left and right windows. Please check before fitting.	es to
JERS X 1	2. Place the window grille / blank into the window aperture. If the tabs are perforated bend along the perforation line using pliers so it fits correct the second	
	into the window aperture. Take care not to weaken the tabs by bending them the wrong way. If the tabs are not perforated do not bend the	
RILL (Ø3.2MM) X 1	3. Once happy with the position of the grille / blank carefully drill 3.2n holes for the self-tapping screws. Take care not to catch any wires.	
	4. Secure in place using the self-tap screws provided. Regularly insp all fixings and parts. Any damaged or worn parts should be immediate	pect •

This FITTING INSTRUCTION is the property of VAN GUARD ACCESSORIES LTD. and must not be used for manufacturing purposes, copied nor communicated in any way to third parties without written permission from VAN GUARD ACCESSORIES LTD. IN8063 B

Van Guard Accessories Ltd Fair Oak Close, Exeter Airport Business Park, Exeter, Devon, EX5 2UL www.van-guard.co.uk

IN8063 - PAGE 1 OF 1