IN9307 Internal Shield - Twin Rear Door

THANK YOU FOR PURCHASING A VAN GUARD INTERNAL SHIELD



This FITTING INSTRUCTION is the property of VAN GUARD ACCESSORIES LTD. and must not be used for manufacturing purposes, copied nor communicated in any way to third parties without written permission from VAN GUARD ACCESSORIES LTD. IN9307 A

Van Guard Accessories Ltd Fair Oak Close, Exeter Airport Business Park, Exeter, Devon, EX5 2UL www.van-guard.co.uk

IN9307 - PAGE 1 OF 7







IN9307 - PAGE 3 OF 7

2.1. REMOVAL OF INTERNAL RELEASE HANDLE

2.2. REMOVAL OF INTERNAL RELEASE HANDLE

Remove the inner door handle assembly as a complete unit. There is a hook/tab in the top of the assembly which needs to be unclipped to allow the top to slide across from right to left.



To allow the assembly to be fully removed, press inward the tab on the underside of the assembly. This is shown in Fig. 2 outside of the door for easy identification



IN9307 - PAGE 4 OF 7

2.3. REMOVAL OF INTERNAL RELEASE HANDLE

3. POSITIONING THE SHIELD

Once the tab is depressed the whole assembly can slide from right to left and be removed from the door. There is no need to disconnect any cables.



Insert the shield into the door aperture behind the handle assembly. Hook the cable protection tab in first (FIG.1), then the bottom of the shield (FIG.2) and press up into position (FIG.3).







5. REFITTING THE DOOR PANEL

With the shield fixed into position, refit the door handle assembly by positioning it back in its aperture, ensuring it is hooked over the door skin correctly, slide from left to right to locate it into place. Then refit the door card over the handle assembly and fix into place using the plastic clips.

