IN9381 External Shield - Sliding Door

THANK YOU FOR PURCHASING A VAN GUARD EXTERNAL SHIELD



This FITTING INSTRUCTION is the property of VAN GUARD ACCESSORIES LTD. and must not be used for manufacturing purposes, copied nor communicated in any way to third parties without written permission from VAN GUARD ACCESSORIES LTD. IN9381 C (CN:00164)

Van Guard Accessories Ltd Fair Oak Close, Exeter Airport Business Park, Exeter, Devon, EX5 2UL www.van-guard.co.uk

IN9381 - PAGE 1 OF 5





IN9381 - PAGE 2 OF 5

1. REMOVAL OF INTERNAL RELEASE LEVER

2. REMOVAL OF DOOR PANEL

Leave the rear door open while carrying out this installation. Remove the internal release lever. This is refitted at the end of the installation when refitting the door panel.



Remove the door panel cover using a plastic trim removal tool. This is refitted at the end of the installation.



IN9381 - PAGE 3 OF 5

3. REMOVAL OF SOUND PROOFING

4. SHIELD LOCATION

Carefully remove the sound proofing. This is refitted at the end of the installation when refitting the door panel.



Protect the area of the door where the shield will be fitted with masking tape.
Measure 175mm down from the window aperture as shown and mark this location, this is where the top of the rubber gasket will be positioned.



5. POSITIONING THE SHIELD

6. FITTING THE SHIELD

1. Align the top of the gasket with the mark made in step 4.

2. Use the rubber gasket as a template to mark the hole positons. Make sure the gasket is orientated correctly with the yellow backing facing you. The rubber gasket is profiled 1.5mm smaller than the shield so it needs to be offset 1.5mm from the edge of the door.

3. Mark down the ten hole centres.

4. With the door open, carefully drill the fixings holes, using a 4mm pilot then opening to 8mm. Remove any swarf and treat bare metal with anti-corrosion spray.



Stick the rubber gasket to the outer shield and then place the shield in position and secure in place with M6 nyloc nuts and M6 washers. **Take care not to overtighten the nuts, tighten to 9Nm.** Once secure, refit the plastic panel removed in steps 1-3.

