



IN8000 **ULTI Rack**



#	PART NO.	QTY
1	AS3005	-
2	AS3006	4
3	AS3160	1
4	ME0019	1
5	ME0020	1
6	ME0021	6



#	PART NO.	QTY
1	FX4008 (M8)	1
2	FX4027 (M8X55)	8
3	FX4139 (M8X20)	2
4	FX4001 (M8X40)	2
5	FX4007	2
6	MA6007	4
7	FX4036 (M8)	2
8	FX4011 (M8)	8
9	FX4012 (M6X16)	14
10	FX4010 (M6)	14
11	FX4017 (M6)	14
12	FX4126 (M6)	14

## VGUR-001

### Vehicle:

Vauxhall Vivaro: 2002 - 2014



Renault Trafic: 2002 - 2014

Nissan Primastar: 2002 on

Wheel Base: SWB (L1)

Roof Height: Low (H1)

Rear Doors: Twin



## VGUR-002

### Vehicle:

Vauxhall Vivaro: 2002 - 2014



Renault Trafic: 2002 - 2014

Nissan Primastar: 2002 on

Wheel Base: SWB (L1)

Roof Height: Low (H1)

Rear Doors: Tailgate



## VGUR-003

### Vehicle:

Vauxhall Vivaro: 2002 - 2014



Renault Trafic: 2002 - 2014

Nissan Primastar: 2002 on

Wheel Base: LWB (L2)

Roof Height: Low (H1)

Rear Doors: Twin



## VGUR-004

### Vehicle:

Vauxhall Vivaro: 2002 - 2014



Renault Trafic: 2002 - 2014

Nissan Primastar: 2002 on



Wheel Base: LWB (L2)

Roof Height: Low (H1)


Rear Doors: Tailgate



## TOOLS REQUIRED




FX4008 (M8) X1  
(SUPPLIED IN FIXING KIT)




ME0182 X1  
(SUPPLIED IN FIXING KIT)


1




ME0019





ME0020




ME0021




2 Secure the fixing clips (FX4126) to the vehicles fixing points as shown below.




3 Secure the rear / middle roof brackets (ME0021) to the vehicles fixing points using M6x16 hex bolts, M6 shakeproof washers and M6 washers. See page three to ensure the brackets are positioned on the correct fixing points.




- 4** Secure the front roof brackets (ME0019 / ME0020) to the vehicles fixing points using M6x16 hex bolts, M6 shakeproof washers and M6 washers. See page three to ensure the brackets are positioned on the correct fixing point.




- 5** Loosely secure roof bars to the roof brackets using M8x55 coach bolts and M8 flange nuts.




- 6** Adjust the roof bars to ensure that they're evenly spaced on the vehicle.



- 7** Tighten the M8 flange nuts.




# 8.1




# 8.2

Lift the rear side rail sections into position (A2 & B2). Ensure that the side rails are connected to the roof bars correctly as per step 8.3.




# 8.3




# 9


Adjust the position of the rear side rails to suit the rear roller. If fitting to a tailgate model, adjust position with the tailgate open to ensure enough clearance.




**10** Push on the lever to secure the 2X rear fixed roof bars into position.




**11** Lift the front side rail sections into position (A1 & B1). Ensure that the side rails are connected to the roof bars correctly as per step 8.3.



**12** Slide the front side rail up to the rear side rail and secure together using 1X M8x40 button bolt. Tighten using the supplied tool (FX4008). Repeat for the other side.




**13** Push on the lever to secure the 2X front fixed roof bars into position.






**14** Place the remaining roof bars into position. See page 2 for the recommended distances between the roof bars. Once in position push on the lever to secure in place.


\*IMAGE FOR ILLUSTRATION PURPOSES ONLY




**15** Secure the roller spigot to the left hand roller bracket only using a M8 t bolt (FX4139) and a M8 shakeproof washer. Ensure that the shakeproof is on the inside of the roller bracket and that the spigot sits flush / straight. Tighten using the supplied tool.




**16** Assemble the roller spigot, M8 t bolt (FX4139) and M8 shakeproof washer together. Place the assembly into the roller. Slide the roller onto the spigot fitted in step 15, drop the other end into position and then tighten using the supplied tool (ME0182).



**17** Push the plastic bungs into position (X4).



**18** Check bars are fully secured.



**19** Once the product has been fitted check fixings and parts to ensure they have been fully secured and tightened. Check fixings and parts at regular intervals. Any damaged or worn parts must be immediately removed from the vehicle and replaced.



**NOTES:**

Maximum load capacity: 150KG (Including rack weight - please refer to page 2.) (Maximum load must be in accordance with the vehicle manufacturer's load bearing capacity. Please refer to the vehicle's handbook.) Regularly check all fixings and parts.  
Retain these instructions for future reference. It is important that the end user receives this document.